

Item #1000 723 883
Model #VT631506




USE AND CARE GUIDE

30-GALLON PORTABLE AIR COMPRESSOR

Questions, problems, missing parts?
Before returning to the store, call
Husky Customer Service
8 a.m. - 6 p.m., EST, Monday - Friday

1-888-43-HUSKY

HUSKYTOOLS.COM



Questions, problems, missing parts? Before returning to the store,
call Husky Customer Service
8 a.m.-6 p.m., EST, Monday-Friday

1-888-43-HUSKY

HUSKYTOOLS.COM

Retain this manual for future use.

Document Number IN639700AV 7/13

THANK YOU

We appreciate the trust and confidence you have placed in Husky through the purchase of this air compressor. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Husky!

Table of Contents

Safety Information	2	Pre-Assembly	12
California Proposition 65	2	Assembly	13
General Safety	3	Pre-Operation - Electrical	14
Work Area Safety	4	Operation	15
Personal Safety	5	Maintenance	17
Electrical Safety	5	Care and Cleaning	19
Spraying Precautions	5	Troubleshooting	22
Warranty	6	Service Parts	24
Pre-Installation	7		
Tools Required	7		
Hardware Required	7		
Package Contents	8		
Specifications	9		
Compressor Components	10		

Safety Information

This manual contains information that is very important to know and understand. This information is provided for SAFETY and to PREVENT EQUIPMENT PROBLEMS. To help recognize this information, observe the following symbols.



DANGER: Indicates an imminently hazardous situation which, if not avoided, WILL result in death or serious injury.



WARNING: Indicates a potentially hazardous situation which, if not avoided, COULD result in death or serious injury.



CAUTION: Indicates a potentially hazardous situation which, if not avoided, MAY result in minor or moderate injury.



IMPORTANT: Indicates important information, that if not followed, may cause damage to equipment.



NOTE: Information that requires special attention.

CALIFORNIA PROPOSITION 65



WARNING: This product or its power cord may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.



WARNING: You can create dust when you cut, sand, drill, or grind materials such as wood, paint, metal, concrete, cement, or other masonry. This dust often contains chemicals known to cause cancer, birth defects, or other reproductive harm. Wear protective gear.

Service Parts - Pump (continued)

Part	Description	Part Number	Quantity
1	Crankcase	VT040300AV	1
2	Ball bearing	ST084202AV ▲	2
3	Crankshaft	▲	1
4	O-ring	■ ●	1
5	Oil seal	ST129700AV ■ ●	1
6	Bearing cap	●	1
7	Cap screw, M6 - 1.00 x 12	--	4
8	Connecting rod	VT040100AV ◆	2
9	Piston head	◆	2
10	Piston pin	VS001400AV	2
11	Piston ring set	VT911200AV	2
12	Hex head cap screw	▼	4
13	Flange head screw	▼	2
14	Air filter assembly	VH901700AV	1
15	Air filter element	VH901800AV	1
16	Pump head	▼	1
17	Valve plate gasket	■ ★	1
18	O-ring	VT036700AV ★	1
19	Valve plate	★	1
20	Cylinder gasket	■ ★	1
21	Cylinder	VT040715AV	1
22	Crankcase gasket	■	1
23	Breather	VH901100AV	1
24	Sight glass	ST191700AV	1
25	Oil drain plug	ST022300AV	1

REPLACEMENT PARTS KITS


▲	Crankshaft kit	VT040650AV
■	Gasket Kit	VT470900AJ
●	Bearing cap assembly kit	VT040200AJ
◆	Connecting rod and piston head kit	VT020500AV
▼	Cylinder head and fasteners kit	TQ900800AJ
★	Valve plate assembly kit	VT491100AV
--	Not available	

TORQUES

	Head bolts	225-300 in. lbs.
	Bearing cap bolts	55-120 in. lbs.
	Sight glass	55 in. lbs.
	Flywheel	320-350 in. lbs.
	Pulley	70-100 in. lbs.

Service Parts - Pump

MODEL VT482200AJ



Safety Information (continued)

GENERAL SAFETY

! DANGER: Breathable Air Warning: This compressor/pump is NOT equipped and should NOT be used "as is" to supply breathing quality air. For any application of air for human consumption, you must fit the air compressor/pump with suitable in-line safety and alarm equipment. This additional equipment is necessary to properly filter and purify the air to meet minimal specifications for Grade D breathing as described in Compressed Gas Association Commodity Specification G 7.1, OSHA 29 CFR 1910. 134, and/or Canadian Standards Associations (CSA).

Disclaimer of Warranties: In the event the compressor is used for the purpose of breathing air application and proper in-line safety and alarm equipment is not simultaneously used, existing warranties are void, and the Manufacturer disclaims any liability whatsoever for any loss, personal injury or damage.

! DANGER: Never attempt to repair or modify a tank! Welding, drilling, or any other modification will weaken the tank, resulting in damage from rupture or explosion. Always replace worn, cracked, or damaged tanks.

! WARNING: Never install a shut-off valve between the compressor pump and the tank. Personal injury and/or equipment damage may occur. Never use reducers in discharge piping.

! CAUTION: See the compressor specification decal for maximum operating pressure. Do not operate with pressure switch or pilot valves set higher than the maximum operating pressure.

! IMPORTANT: Drain liquid from the tank daily.

! NOTE: The **DANGER**, **WARNING**, **CAUTION**, **IMPORTANT**, and **NOTE** notifications and instructions in this manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that caution is a factor which cannot be built into this product, but must be supplied by the operator.

1. Read all manuals included with this product carefully. Be thoroughly familiar with the controls and the proper use of the equipment.
2. Only persons well acquainted with these rules of safe operation should be allowed to use the compressor.
3. Tanks rust from moisture build-up, which weakens the tank. Make sure to drain the tank regularly and inspect periodically for unsafe conditions, such as rust formation and corrosion.
4. Fast moving air will stir up dust and debris which may be harmful. Release air slowly when draining moisture or depressurizing the compressor system.

Safety Information (continued)

WORK AREA SAFETY



WARNING: Motors, electrical equipment, and controls can cause electrical arcs that will ignite a flammable gas or vapor. Never operate or repair in or near a flammable gas or vapor. Never store flammable liquids or gases in the vicinity of the compressor.



WARNING: An ASME code safety relief valve with a setting no higher than the maximum allowable working pressure (MAWP) MUST be installed in the tank for this compressor. The ASME safety valve must have sufficient flow and pressure ratings to protect the pressurized components from bursting.



WARNING: Never use plastic (PVC) pipe for compressed air. Serious injury or death could result.



WARNING: This compressor is extremely top heavy.



WARNING: Do not modify this compressor. Do not use or create accessories not recommended for use with this compressor. Alterations and/or modifications are a form of misuse, which could result in a hazardous condition leading to possible personal injury or equipment damage.



CAUTION: Do not use this compressor in an environment where the air is contaminated or dusty. Using this compressor in such an environment may cause equipment damage.

1. Keep visitors away from the compressor, and NEVER allow children in the work area.
2. Before each use, inspect the compressed air system and electrical components for signs of damage, deterioration, weakness, or leakage. Repair or replace defective items before using.
3. Check all fasteners at frequent intervals for proper tightness.
4. If the equipment should start to vibrate abnormally, STOP the engine/motor and check immediately for the cause. Vibration is generally a warning of trouble.
5. To reduce fire hazard, keep the engine/motor exterior free of oil, solvent, or excessive grease.
6. Never attempt to adjust the ASME safety valve. Keep the safety valve free from paint and other accumulations.


Service Parts - Compressor (continued)

Part	Description	Part Number	Qty.
1	Tank	AR059400CG	1
2	Drain valve	D-1403	1
3	Electric motor	MC019800SJ	1
4	Key	KE000900AV	1
5	Hex head screw	ST070692AV	4
6	Washer	ST011200AV	4
7	Locknut	ST146001AV	6
8	Nipple	ST016800AV	1
9	Pressure switch	CW209000AV	1
10	Motor cord (not shown)	EC012800AV	1
11	ASME Safety valve	V-215105AV	1
12	90° Fitting	ST071230AV	1
13	Gauge	GA016306AV	2
14	Unloader valve	CW210001AV	1
15	Check valve	CV221502SJ	1
16	Ferrule	ST085200AV	1
17	Exhaust tube	VT046800AP	1
18	Compression nut	ST033001AV	2
19	Push-in fitting	ST081301AV	1
20	Unloader tube	ST117802AV	1
21	Pump	VT482200AJ	1
22	Handle grip	HL705900AV	2
23	Compression assembly	ST018300AV	1
24	Self-tapping screw	ST073275AV	4
25	Belt	BT013001AV	1
26	Flywheel with key and set screw	PU015901SJ	1
27	Pulley	PU015200AV	1
28	Square hd set screw	ST012200AV	1
29	Plastic belt guard (back)	BG222300AV	1
30	Plascrew	ST058502AV	1
31	Plastic belt guard (front)	BG222200AV	1
32	Self-tapping screw	ST073269AV	1
33	Self-tapping screw	ST073278AV	3
34	Air filter assembly	VH901700AV	1
35	Air filter element (not shown)	VH901800AV	1

Part	Description	Part Number	Qty.
36	Handle	HL041900AV	2
37	Handle screw	ST073273AV	4
38	Wheel	WA006000AV	2
39	Axle bolt	ST084700AV	2
40	Nut	ST033500AV	2
41	Foot	ST162601AV	2
42	Washer	ST070930AV	2
43	Reducer	ST071407AV	1
44	Reducer bushing	ST071428AV	1
45	Nipple	HF002401AV	1
46	Regulator	RE300000AJ	1
47	Power cord	EC012601AV	1
48	Clamp	CW209500AV	1
49	Screw	ST209800AV	1
50	Screw	ST074407AV	2
51	General warning decal set (not shown)	DK747600AV	1
52	Moving and mounting warning decal (not shown)	DK364601AV	1
53	Oil drain extension (not shown)	ST083800AV	1
54	Oil drain extension cap (not shown)	ST150100AV	1
55	Motor cord	EC012800AV	1

Service Parts - Compressor

MODEL VT631506



Safety Information (continued)

PERSONAL SAFETY

WARNING: Never operate the compressor without a beltguard. This unit can start automatically without warning. Personal injury or property damage could occur from contact with moving parts.

CAUTION: Compressor parts may be hot even if the unit is stopped.

1. Wear safety glasses and use hearing protection when operating the unit.
2. Do not stand on or use the unit as a handhold.
3. Do not wear loose clothing or jewelry that will get caught in the moving parts of the unit.
4. Keep fingers away from a running compressor; fast moving and hot parts will cause injury and/or burns. Compressor parts may be hot even if the unit is stopped.

ELECTRICAL SAFETY

WARNING: Overheating, short-circuiting, and fire damage may result from inadequate wiring.

CAUTION: Improper installation of the grounding plug is capable in resulting in electrical shock. When repairing or replacing the cord or plug, do not connect the grounding wire to either flat blade terminal to by-pass the grounding pin. The grounding wire is usually the green-colored (with or without yellow stripes) insulated wire.

1. Follow all local electrical and safety codes as well as in the United States, the National Electrical Codes (NEC), and Occupational Safety and Health Act (OSHA).
2. Avoid body contact with grounded surfaces such as pipes, radiators, ranges, and refrigerators. There is an increased risk of electric shock if your body is grounded.
3. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
4. Replace damaged cords/wiring immediately. Damaged cords/wiring increase the risk of electric shock.

SPRAYING PRECAUTIONS

WARNING: Do not spray flammable materials in vicinity of open flame or near ignition sources including the compressor unit.

1. Do not smoke when spraying paint, insecticides, or other flammable substances.
2. Use a face mask/respirator when spraying and spray in a well ventilated area to prevent health and fire hazards.
3. Do not direct paint or other sprayed material at the compressor. Locate the compressor as far away from the spraying area as possible to minimize overspray accumulation on the compressor.
4. When spraying or cleaning with solvents or toxic chemicals, follow the instructions provided by the chemical manufacturer.

Warranty

LIMITED TWO-YEAR WARRANTY

WHAT IS COVERED

From the date of purchase, parts and labor are covered to remedy substantial defects due to material and workmanship during the first year of ownership with the exceptions noted below. From the date of purchase, parts only are covered to remedy substantial defects due to material and workmanship during the second year of coverage with exceptions noted below.

This warranty applies only to the original retail purchaser and may not be transferred. If the compressor is used for commercial, industrial, or rental purposes, the warranty will apply for ninety (90) days from the date of purchase. Two-stage compressors are not limited to a ninety (90) day warranty when used in commercial or industrial applications. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

WARRANTOR: Campbell Hausfeld/Scott Fetzer Company, 100 Production Drive, Harrison, Ohio, 45030 Telephone: (800) 543-6400

The responsibilities of the warrantor under this warranty is to repair or replace, at the warrantor's option, this compressor or components which are defective, have malfunctioned, and/or have failed to conform within the duration of the specific warranty period. Repair or replacement will be scheduled and serviced according to the normal work-flow at the servicing location and will depend on the availability of replacement parts.

The responsibilities of the purchaser under this warranty are as follows: a) provide dated proof of purchase and maintenance records; b) call to obtain your warranty service options [freight costs must be borne by the purchaser]; c) use reasonable care in the operation and maintenance of the products as described in the owner's manual(s); d) repairs requiring overtime, weekend rates, or anything beyond the standard manufacturer warranty repair labor reimbursement rate; e) time required for any security checks, safety training, or similar for service personnel to gain access to facility; and f) location of unit must have adequate clearance for service personnel to perform repairs and easily accessible.

WHAT IS NOT COVERED

This warranty does not cover normal wear and tear or any malfunction, failure, or defect resulting from misuse, abuse, neglect, alteration, modification, or repair by other than a service center authorized by the manufacturer to repair this air compressor. Expendable materials, such as motor brushes, seals, etc. are not covered by this warranty. This warranty does not apply to this compressor used in industrial applications or for rental purposes. Husky makes no warranties, representations, or promises as to the quality or performance of its air compressors other than those specifically stated in this warranty.

Implied warranties, including those of merchantability and fitness for a particular purpose, are limited to two years from the date of original purchase by the consumer. Any incidental, indirect, or consequential loss, damage, or expense that may result from any defect, failure, or malfunction of the manufacturer's product is not covered by this warranty. Some states do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you. The warranty does not cover any failure that results from an accident, purchaser's abuse, neglect, or failure to operate products in accordance with instructions provided in the owner's manual(s) supplied with compressor.

This warranty does not cover pre-delivery service, i.e. assembly, oil or lubricants, and adjustment. This warranty does not cover items or service that is normally required to maintain the product, i.e. lubricants, filters, gaskets, etc.

Gasoline engines and components are expressly excluded from coverage under this limited warranty. The purchaser must comply with the warranty given by the engine manufacturer which is supplied with the product.

The following items not covered under this warranty. This warranty excludes these items (pertaining to all compressors) as follows: a) any component damaged in shipment or any failure caused by installing or operating unit under conditions not in accordance with installation and operation guidelines or damaged by contact with tools or surroundings; b) pump or valve failure caused by rain, excessive humidity, corrosive environments, or other contaminants; c) cosmetic defects that do not interfere with compressor functionality; d) rusted tanks, including but not limited to rust due to improper drainage or corrosive environments; e) any components that are considered normal wear items and are not covered after the first year of ownership [the electric motor, check valve, pressure switch, regulator, pressure gauges, hose, tubing, pipe, fittings and couplers, screws, nuts, hardware items, belts, pulleys, flywheel, air filter and housing, gaskets, seals, oil leaks, air leaks, oil consumption or usage, piston rings]; f) the tank drain valves; g) damage due to incorrect voltage or improper wiring; h) other items not listed but considered general wear parts; i) pressure switches, air governors, load/unload devices, throttle control devices, and safety valves modified from factory settings; j) damage from inadequate filter maintenance; and k) induction motors operated with electricity produced by a generator.

The following items not covered under this warranty. This warranty excludes these items (specific to lubricated compressors) as follows: a) pump wear or valve damage caused by using oil not specified; b) pump wear or damage caused by any oil contamination; and c) pump wear or damage caused by failure to follow proper oil maintenance guidelines, operation below proper oil level, or operation without oil.

Labor, service calls, or transportation charges after the first year of ownership are not covered on stationary air compressors. Stationary air compressors are defined as those units not including a handle or wheels.

This Limited Warranty applies in the U.S., Canada, and Mexico only This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

How to get service: Call 1-888-43-HUSKY or visit www.HUSKYTOOLS.com.

Troubleshooting (continued)

Problem	Possible Cause	Solution
The motor hums and runs slowly, or the motor does not run at all.	<p>The voltage is low.</p> <p>There are too many devices on same the circuit.</p> <p>The electrical connections are loose.</p> <p>The pressure switch is malfunctioning - the contacts will not close.</p> <p>The check valve is malfunctioning.</p> <p>The unloader valve on the pressure switch is defective.</p> <p>The motor capacitor(s) are defective.</p> <p>The motor is defective.</p> <p>Use of an extension cord</p>	<p>Check incoming voltage. It should be approximately 120 volts.</p> <p>Limit the circuit to the use of the compressor only.</p> <p>Check all the electrical connections.</p> <p>Replace the pressure switch.</p> <p>Replace the check valve. Do not disassemble the check valve with air pressure in the tank.</p> <p>Replace the unloader valve.</p> <p>Replace the capacitor(s).</p> <p>Replace the motor.</p> <p>Do not use an extension cord. Use a longer air hose with a larger diameter.</p>
The reset mechanism cuts out repeatedly or the circuit breaker trips repeatedly.	<p>There is not proper ventilation for the air compressor unit, or the room temperature too high.</p> <p>There are too many devices on the same circuit.</p> <p>The air intake is restricted.</p> <p>The electrical connections are loose.</p> <p>The pressure switch shut-off pressure is set too high.</p> <p>The check valve is malfunctioning.</p> <p>The unloader valve on the pressure switch is defective.</p> <p>The motor capacitor(s) are defective.</p> <p>The motor is defective.</p> <p>Use of an extension cord</p>	<p>Move the compressor to a well-ventilated area.</p> <p>Limit the circuit to the use of only the air compressor.</p> <p>Clean or replace the air filter element.</p> <p>Check all the electrical connections.</p> <p>Replace the pressure switch.</p> <p>Replace the check valve. Do not disassemble the check valve with air pressure in the tank.</p> <p>Replace the unloader valve.</p> <p>Replace the capacitor(s).</p> <p>Replace the motor.</p> <p>Do not use an extension cord. Use a longer air hose with a larger diameter.</p>
The tank does not hold pressure when the compressor is off and the shut off valve is closed.	<p>There are air leaks in the fittings, tubing on the compressor, or the plumbing outside the unit.</p> <p>The check valve is worn.</p> <p>Check the tank for cracks or pin holes.</p>	<p>Listen for escaping air. Apply soap solution to all fittings and connections. Bubbles will appear at points of leakage. Tighten or replace leaking fittings or connections. Use pipe thread sealant.</p> <p>Replace the check valve. Do not disassemble the check valve with air pressure in the tank.</p> <p>Replace the tank. Never try to repair a damaged tank.</p>
The pressure switch continuously blows air out the unloader valve.	<p>The check valve is malfunctioning.</p>	<p>Replace the check valve if the unloader valve on the pressure switch bleeds off constantly when the unit shuts off. Do not disassemble the check valve with air pressure in the tank.</p>
There is excessive vibration.	<p>The fasteners on the pump or the motor are loose.</p> <p>The belt needs to be replaced.</p> <p>The belt needs to be aligned.</p>	<p>Tighten the fasteners.</p> <p>Replace the belt. Make sure to use the correct size.</p> <p>Align the flywheel and the pulley.</p>

Troubleshooting

Problem	Possible Cause	Solution
The discharge pressure is low.	<p>The air demand exceeds the pump capacity.</p> <p>The air intake is restricted.</p> <p>There are air leaks in the fittings, tubing on the compressor, or the plumbing outside the unit.</p> <p>There are blown gaskets.</p> <p>There are leaking or damaged valves.</p>	<p>Reduce the air demand or use a compressor with more capacity.</p> <p>Clean or replace the air filter element.</p> <p>Listen for escaping air. Apply soap solution to all fittings and connections. Bubbles will appear at points of leakage. Tighten or replace leaking fittings or connections. Use pipe thread sealant.</p> <p>Replace any gaskets proven faulty on inspection.</p> <p>Remove the head and inspect for valve breakage, misaligned valves, damaged valve seats, etc. Replace defective parts and reassemble. Install a new head gasket each time the head is removed.</p>
The air compressor unit is making excessive noise (a knocking sound).	<p>The motor pulley or the flywheel is loose.</p> <p>The fasteners on the pump or the motor are loose.</p> <p>There is no oil in the crankcase.</p> <p>The connecting rod is worn.</p> <p>The piston pin bores are worn.</p> <p>The piston is hitting the valve plate.</p> <p>There is a noisy check valve in the compressor system.</p>	<p>Tighten the pulley/flywheel clamp bolts and the set-screws.</p> <p>Tighten the fasteners</p> <p>Check for proper oil level; if the oil level is low, check for possible damage to the bearings. Dirty oil can cause excessive wear.</p> <p>Replace the connecting rod. Maintain the oil level and change the oil more frequently.</p> <p>Remove the piston assemblies from the compressor and inspect for excess wear. Replace the excessively worn piston pin or pistons, as required. Maintain the oil level and change the oil more frequently.</p> <p>Remove the compressor head and the valve plate and inspect for carbon deposits or other foreign matter on the top of the piston. Replace the head and the valve plate using the new gasket. See the Lubrication section for the recommended oil type.</p> <p>Replace the check valve. Do not disassemble the check valve with air pressure in the tank.</p>
<p>There is a large quantity of oil in the discharge air.</p> <p>NOTE: In an oil lubricated compressor there will always be a small amount of oil in the air stream.</p>	<p>The piston rings are worn.</p> <p>The compressor's air intake is restricted.</p> <p>There is excessive oil in the compressor.</p> <p>The oil viscosity is wrong.</p>	<p>Replace with new rings. Maintain the oil level and change the oil more frequently.</p> <p>Clean or replace the filter. Check for other restrictions in the intake system.</p> <p>Drain oil down to the correct full level.</p> <p>Only use Mobil 1® 10W-30 or SAE 30 compressor oil.</p>
There is water in the discharge air/tank.	<p>This is normal during operation.</p> <p>The amount of water increases with humid weather.</p>	<p>Drain the tank more often. At least daily.</p> <p>Add a filter/dryer to reduce the amount of water in the air line.</p>
The pressure switch does not release air when the unit shuts off.	The unloader valve on the pressure switch is malfunctioning.	Replace the unloader valve if it does not release the pressure for a short period of time when the unit shuts off. Do not disassemble the check valve with air pressure in the tank.

Pre-Installation

PLANNING INSTALLATION

IMPORTANT: This compressor is not intended for outdoor installation.

It is extremely important to use the compressor in a clean, well ventilated area where the surrounding air temperature will not be more than 100°F. Provide a minimum clearance of 18 in. between the compressor flywheel or fan and the wall. Do not locate the compressor air inlet near steam, paint spray, sandblast areas, or any other source of contamination.

TOOLS REQUIRED



HARDWARE INCLUDED


NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	Foot bolt	2
BB	Locknut	2

Pre-Installation (continued)


COMPRESSOR COMPONENTS



Maintenance (continued)

7 Checking the air filter

Remove the nut (1) and the washer (2).
 Remove the air filter cover (3) from the air filter base (5).
 Remove and inspect the air filter element (4).
 If the air filter element is dirty, replace it. Install a new filter element. If the air filter element is clean, reinstall it.
 Reattach the air filter cover (3).
 Reattach the washer (2) and the nut (1). Do not overtighten the nut as this maintenance process will be repeated regularly. The nut (1) should be snug enough to hold the air filter cover (3) in place.



MAINTENANCE SCHEDULE

WARNING: Disconnect, tag, and lock out the power source, and then release all pressure from the system before attempting to install, service, relocate, or perform any maintenance.

Operation	Daily	Weekly	Monthly	Every 3 Months
Check Oil Level	X			
Drain Tank	X			
Check Air Filter		X		
Check Safety Valve		X		
Clean Unit			X	
Check Belt Tension			X	
Change Oil				X

IMPORTANT: Change oil after the first fifty (50) hours of operation. Then perform oil changes every three (3) months.

Care and Cleaning

WARNING: Disconnect, tag, and lock out the power source, and then release all pressure from the system before attempting to install, service, relocate, or perform any maintenance.

Keep all surfaces clear of debris and dirt.
 Do not attempt to clean the unit while running. Turn off the unit, disconnect it from the mains, and allow the unit to cool down.
 Check the air filter weekly to see if it needs to be cleaned. Remove the filter element. Use hot, soapy water to clean the filter and allow the filter to dry before reinstalling and returning the unit to active duty. Replace a filter that cannot be cleaned.

Maintenance (continued)

4 Checking the belt


Remove the beltguard screw (1).

Remove the front beltguard (2). The beltguards are held together by pressure snap-latches (3). Wedge a flathead screwdriver between the beltguards at the snap-latches.

Wedge a screwdriver at the other snap-latch junctions. Twist and separate the snap-latches until the front beltguard comes completely off.

If the belt appears to be in working order and has no signs of damage, return the rear beltguard to the original position and snap it back in place. Tighten the beltguard screw.

If the belt needs to be replaced, move on to the next step.



5 Removing the belt


Loosen (but do not remove) the four bolts (1) holding the motor in place.

Shift the motor towards the pump. The belt should be slack and easily removed.

Replace the belt.

Move the motor back to the original position to create belt tension.

Tighten the motor bolts.



6 Aligning/tensioning the belt

Lay a straightedge (1) against the face of the flywheel touching the rim at two places (2,3).


Adjust the flywheel or motor pulley so that the belt (4) runs parallel to the straightedge. Use a gear puller to move the pulley on the motor shaft. Tighten the setscrew after the pulley is positioned.

Adjust the motor's distance from the pump if needed.

Belt tension is determined by how much the belt moves when weight is applied. The belt should move no more than 3/8 to 1/2 in. downward if normal thumb pressure is placed on it.

Tighten the motor bolts once the proper belt tension is achieved.

Reattach the belt guard.



	Bolt Torque
Flywheel	320-350 in. lbs.
Pulley	70-100 in. lbs.

Pre-Installation

COMPRESSOR COMPONENTS

Part	Description
A	Pressure Switch (AUTO/OFF Switch) - In the AUTO position, the compressor shuts off automatically when the tank pressure reaches the maximum preset pressure. After air is used from the tank and drops to a preset low level, the pressure switch automatically turns the motor back on. In the OFF position, the compressor will not operate. This switch should be in the OFF position when connecting or disconnecting the power from the unit. When the pressure switch turns the motor off you will hear air leaking out of the pressure switch unloader valve for a short time. This releases the air pressure from the discharge tube and allows the compressor to restart easier.
B	ASME Safety Valve - This valve automatically releases air if the tank pressure exceeds the preset maximum.
C	Discharge Tube - This tube carries compressed air from the pump to the check valve. This tube becomes very hot during use. To avoid the risk of severe burns, never touch the discharge tube.
D	Check Valve - One-way valve that allows air to enter the tank, but prevents air in the tank from flowing back into the compressor pump.
E	Belt Guard - Covers the belt, motor pulley, and flywheel.
F	Drain Valve - Use this valve to drain moisture from the tank daily to reduce the risk of corrosion.
G	Tank Pressure Gauge - Indicates the amount of air pressure stored in the tank.
H	Outlet Pressure Gauge - Indicates the amount of air pressure being delivered out the discharge port.
I	Air Filter - Keeps large particulates out of the air flowing into the compressor.
J	Regulator - Controls the amount of air pressure released at the discharge port.
K	Discharge Port - Air delivery port for transfer of compressed air.
L	Oil Fill/Breather - This is where oil is added to the crankcase. It also allows the crankcase to vent.
M	Oil Drain - This is where the oil is drained from the crankcase to change the oil.
N	Sight Glass - This is where the oil level is checked.
O	Motor Thermal Overload - This device protects the motor from overheating by shutting it off if it gets too hot. When the motor is completely cool, the protector can be reset if it has tripped, by pushing the reset button.

Pre-Assembly

1 Removing from the shipping pallet



WARNING: Disconnect, tag, and lock out the power source, and then release all pressure from the system before attempting to install, service, relocate, or perform any maintenance.



WARNING: This compressor is extremely top heavy. Enlist additional help to remove it from the shipping skid.



CAUTION: Never use the shipping skid for mounting the compressor.



IMPORTANT: Provide a minimum clearance of 18 in. between the compressor flywheel or fan and the wall, and ensure clear access to the drain valve to facilitate condensate drainage.



IMPORTANT: It is extremely important to use the compressor in a clean, well ventilated area where the surrounding air temperature will not be more than 100°F.



IMPORTANT: Do not locate the compressor air inlet near steam, paint spray, sandblast areas, or any other source of contamination.



IMPORTANT: This compressor is not intended for long-term exposure to outdoor use.


Unbolt the air compressor unit (A) from the shipping skid. Use a ratchet with a 1/2 in. socket.

Remove the bolts holding the rear leg in place.

Remove the bolts holding the shipping plates (1) in place at the front of the air compressor unit (A).

Remove the air compressor unit (A) from the skid. This may require at least two people - one person to carefully roll the unit off the skid and one to help maintain balance so the unit does not topple.

Place the air compressor unit (A) on a flat surface to install foot bolts.



Maintenance

GENERAL MAINTENANCE

All repairs should be performed by an authorized service representative.



WARNING: Disconnect, tag, and lock out the power source, and then release all pressure from the system before attempting to install, service, relocate, or perform any maintenance.

1 Checking and changing the oil

Maintain proper oil level by checking the oil sight glass (1) daily. Change the oil in the pump every 3 months. Use the following procedure to change (or add) oil. Remove the oil drain plug from the base of the pump and install the oil drain extension. Some models include an oil drain extension and cap (found with the owner's manual). Install the oil drain extension and cap before adding oil to the pump. To avoid oil leaks, apply pipe thread sealant or thread tape to the threads on each end of the oil drain extension. Screw the cap onto one end of the extension. Drain extension part number is ST083800AV and drain extension cap part number is ST150100AV.

Run the compressor for ten minutes to warm up the oil if the unit has not been in use for an extended period of time.


Turn the compressor off and disconnect the compressor from the power source.

Position a pan under the pump drain plug (2) to catch the oil.

Remove the pump drain plug (2) and allow the oil to collect in the pan.

Reinsert the oil drain plug. Remove the breather (3) from the pump. Pour new, unused oil into the pump. Do not overfill.

Reinsert the breather (3) into position. Return power to the compressor for use.



2 Checking the ASME safety valve


Run the air compressor until it reaches cut-out pressure.

Turn the compressor off and disconnect the compressor from the power source.

Put on safety glasses. Protect yourself from fast moving air.

Pull on the ring of the ASME safety valve (1). This releases pressure from the tank. The safety valve should automatically close at approximately 40 - 50 psi.

If the safety valve does not allow air to be released when you pull on the ring, or if it does not close automatically, it MUST be replaced.




3 Draining the tank of moisture

Turn the compressor off and disconnect it from the power source.

Release the pressure from the compressor by pulling on the ASME safety valve. The ASME safety valve should close at approximately 40 - 50 psi.

Open the drain valve (1) underneath the tank. Remaining air pressure will assist in removing moisture from the tank.



Operation (continued)

ON/OFF CYCLING OF THE COMPRESSOR

The air compressor unit (A) is designed to cycle on and off. With the pressure switch knob in the AUTO position, the compressor pumps air into the tank. When the shut-off (preset “cut-out”) pressure is reached, the compressor automatically shuts off.

If the compressor is left in the AUTO position and air is depleted from the tank by use of a tire chuck, tool, etc., the compressor will restart automatically at its preset “cut-in” pressure. When a tool is in use, the compressor will cycle on and off automatically as needed to maintain air pressure in the tank.

MOISTURE IN COMPRESSED AIR



WARNING: Drain the tank every day to prevent corrosion and possible injury due to tank damage. For optimal performance of the tank drain, the tank pressure should be between 10 - 40 psi. Do not operate the drain with more than 40 psi in the tank or the drain valve may be damaged. Drain the tank of moisture daily using the drain valve at the bottom of the tank.



IMPORTANT: This condensation will cause water spots in a paint job, especially when spraying other than water based paints. If sandblasting, it will cause the sand to cake and clog the gun, rendering it ineffective. A filter/dryer in the air line, located as near to the gun as possible, will help eliminate this moisture.



IMPORTANT: Drain liquid from the tank daily.

Moisture in compressed air will form into droplets as it comes from an air compressor pump. When humidity is high or when a compressor is in continuous use for an extended period of time, this moisture will collect in the tank. When using a paint spray or sandblast gun, this water will be carried from the tank through the hose, and out of the gun as droplets mixed with the spray material.

Follow the tank draining instructions in the Maintenance section of this manual.


Assembly

1 Installing the air filter



NOTE: Do not overtighten the filter. Over the life of the unit, you will clean or replace the filter as needed.

Screw the air filter (B) onto the pump air intake.




2 Installing the foot bolts

Have one person tilt the air compressor unit (A) forward slightly to allow access to the foot bar. Secure the air compressor unit (A) properly to ensure the air compressor unit (A) does not tip over or fall forward on the person installing the foot bolts.

Insert the foot bolt (AA) through the foot bar (1). The foot bolt pad should be on the lower side of the foot bar.

Use the ratchet and 1/2 in. socket to tightly secure the locknut (BB). Repeat with the other foot (AA).



Pre-Operation - Electrical

1 Preparing for use

DANGER: Improperly grounded motors are shock hazards. Make sure all the equipment is properly grounded.

WARNING: All wiring and electrical connections must be performed by a qualified electrician familiar with industrial motor controls. Installations must be in accordance with local and national codes.

WARNING: Disconnect, tag, and lock out the power source, and then release all pressure from the system before attempting to install, service, relocate, or perform any maintenance.

WARNING: Overheating, short circuiting, and fire damage will result from inadequate wiring.

IMPORTANT: Damage to the motor from improper electrical voltage or connection will void the warranty.

WARNING: Improper installation of the grounding plug is able to result in a risk of electric shock. When repair or replacement of the cord or plug is required, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire. This product is for use on a nominal 120-V circuit and has a grounding plug similar to the plug illustrated in sketch A in Figure 69.1. Only connect the product to an outlet having the same configuration as the plug. Do not use an adapter with this product.

Local electrical wiring codes differ from area to area. Source wiring and protector must be rated for at least the amperage and voltage indicated on the motor nameplate, and meet all electrical codes for this minimum. The minimum wire size should also meet all electrical codes.

Make sure that the outlet being used is connected to a slow blow fuse type T or a 120V/20 amp circuit breaker (1).

This product must be grounded. This product is equipped with a cord having a grounding wire with an appropriate grounding plug(2).


Check with a qualified electrician or serviceman when the grounding instructions are not completely understood, or when in doubt as to whether the product is properly grounded. Do not modify the plug provided; if it does not fit the outlet, have the proper outlet installed by a qualified electrician. Plug the cord into a properly sized, grounded outlet - 120V, 15 amp (3).

In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. The plug must be plugged into an outlet that is properly installed and grounded in accordance with all local codes and ordinances.

Although extension cord is not recommended, if you must use only a 3 wire extension cord that has a 3 blade grounding plug and a 3 slot receptacle that accepts the plug on the product. When using an extension cord be sure to use one heavy enough to carry the current the product draws.

The distance of the outlet from the electrical box must also be considered. Outlets being used must be wired under the following specifications: the outlet's wiring must be 14 AWG for a distance up to 40 ft. long or must be 12 AWG for a distance up to 70 ft. long.

If the above conditions cannot be met or if nuisance tripping of the current protection device occurs, it may not be possible to operate the compressor from a 120 volt 20 amp circuit (4).



Amp Rating Range	Voltage	Cord Length in Feet								
		120V	25 ft	50 ft	100 ft	150 ft	200 ft	250 ft	300 ft	400 ft
14-16 AMP		16 AWG	12 AWG	10 AWG	8 AWG	6 AWG	6 AWG	4 AWG	4 AWG	2 AWG

Operation

1 Preparing for use

WARNING: Check for proper oil level before operating! Make sure compressor is level before operating or checking oil level

The pump oil level is full (1) as shown.


Use SAE 30 industrial grade air compressor oil or full synthetic motor oil like Mobil 1® 10W30.

Do not exceed the maximum oil capacity of approximately 8.5 ounces.

Do not use regular automotive oil. Additives in regular motor oil can cause valve deposits and reduce pump life.

For maximum pump life, drain and replace oil after the first hour of run time.

Use the sight glass on the pump to determine the oil level. Add oil to the pump if the oil level is low (2).



2 Starting-up and breaking-in the compressor

WARNING: Do not attach air tools to the open end of the hose until start-up is completed and the unit checks okay.

WARNING: Never disconnect threaded joints with pressure in the tank!

Plug the air compressor unit (A) into an appropriate electrical outlet.

Open the tank drain valve. The tank will not readily buildup any pressure.

Move the pressure switch (1) to the AUTO position to run the air compressor unit (A).

Run the air compressor unit (A) for thirty (30) minutes at zero (0) psi (under no load) to break-in the pump parts.

Move the pressure switch (1) to the OFF position, and turn the tank drain valve to shut off air flow. The air compressor unit (A) is now ready for use.

