### Operating Instructions and Parts Manual

PW7005



# **Water Wizard Cleaning Brush Kit**

Please read and save these instructions. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with instructions could result in personal injury and/or property damage! Retain instructions for future reference.

# Operating Instructions Quick-Connect Brush -Garden Pole hose Nut Figure 1

- 1. Pole telescopes for longer reach. Loosen nut (Figure 1), adjust Pole to desired length, retighten nut.
- 2. To use Detergent Dispenser (Figure 2), unscrew Detergent Bottle and pour desired amount of liquid detergent or wax into it. Screw Detergent Bottle onto Detergent Dispenser.


During operation, you can start or stop the release of the detergent or wax by turning the Detergent Release Valve On or Off (Figure 3).

## Detergent Dispenser Detergent Screw Bottle . Detergent Bottle onto Detergent Dispenser Figure 2

#### **Safety Section**


Pole conducts electricity! Watch ADANGER for overhead wires. Avoid power lines.

- Never place eyes or face close to water spray or attachments.
- Keep away from children.
- This product is not intended for recreational use by children.
- · Do not drink from this device.
- To prevent water supply contamination, only use this product when back flow prevention device is present.
- · To protect fine surfaces, only use a clean soft bristle brush.



REMINDER: Keep your dated proof of purchase for warranty purposes! Attach it to this manual or file it for safekeeping.

#### Replacement Parts List



#### For Replacement Parts, Call 1-800-330-0712

Please provide following information:

- -Model number
- -Serial number (if anv)
- -Part description and number as shown in parts list

Address parts correspondence to: The Campbell Group / Parts Dept. 100 Production Drive Harrison, OH 45030 U.S.A.

Ref.		Part	
No.	Description	Number	Qty.
1	Container, detergent	PM255905AV	1
2	Dispenser, detergent	PM255906AV	1
3	Pole with soft grips	PM255908AV	1
4	On/Off valve	AL182000AV	1
5	Nipple	PM255913AV	1
6	Quick connect	PM255910AV	1
7	Seal kit (not shown)	PM255909SJ	1
8	Brush soft bristles	PM265001AV	1
9	Brush stiff bristles	PM265002AV	1

#### Limited Warranty

- DURATION: From the date of purchase by the original purchaser as follows: One Year.
  WHO GIVES THIS WARRANTY (WARRANTOR): Campbell Hausfeld / Scott Fetzer Company, 100 Production Drive, Harrison, Ohio, 45030, Telephone: (800) 330-0712
- WHO RECEIVES THIS WARRANTY (PURCHASER): The original purchaser (other than for purposes of resale) of the Campbell Hausfeld Water-Driven Brush System
- WHAT PRODUCTS ARE COVERED UNDER THIS WARRANTY: Any Campbell Hausfeld Water-Driven Brush System supplied or manufactured by the Warrantor
- WHAT IS COVERED UNDER THIS WARRANTY: Substantial defects on material and workmanship which occur within the duration of the warranty period with the exceptions noted below.
- WHAT IS NOT COVERED UNDER THIS WARRANTY:
  - A. Implied warranties, including those of merchantability and FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED FROM THE DATE OF ORIGINAL PURCHASE AS STATED IN THE DURATION. If this Water-Driven Brush System is used for commercial, industrial or rental purposes, the warranty will apply for ninety (90) days from the date of purchase. Some States do not
  - allow limitation on how long an implied warranty lasts, so the above limitations may not apply to you.

    B. ANY INCIDENTAL, INDIRECT, OR CONSEQUENTIAL LOSS, DAMAGE, OR EXPENSE THAT MAY RESULT FROM ANY DEFECT, FAILURE, OR MALFUNCTION OF THE CAMPBELL HAUSFELD WATER-DRIVEN BRUSH SYSTEM. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.
  - C. Any failure that results from shipping damage, accident, purchaser's abuse, neglect or failure to install and operate Water-Driven Brush System in accordance with instructions provided in the owner's manual(s) supplied with product.
  - D. Pre-delivery service, i.e. assembly, oil or lubricants and adjustment.
  - E. Additional items not covered under the warranty:
    - 1. Normal wear items such as o-rings, valves, rubber washers, brushes
    - 2. Cosmetic defects that do not interfere with functionality.
    - Rusted components.
- 7. RESPONSIBILITIES OF WARRANTOR UNDER THIS WARRANTY: Repair or replace, at Warrantor's option, Water-Driven Brush System or component which is defective, has malfunctioned and/or failed to conform within duration of the warranty period
- 8. RESPONSIBILITIES OF PURCHASER UNDER THIS WARRANTY:
  - A. Provide dated proof of purchase.
  - B. Deliver or ship the Campbell Hausfeld Water-Driven Brush System or component to Campbell Hausfeld. Freight costs, if any, must be borne by the purchaser. C. Use reasonable care in the operation and maintenance of the Water-Driven Brush System as described in the owner's
  - manual(s).
- 9. WHEN WARRANTOR WILL PERFORM REPAIR OR REPLACEMENT UNDER THIS WARRANTY: Repair or replacement will be scheduled and serviced according to the normal work flow at the servicing location, and depending on the availability of replacement parts.

This Limited Warranty applies in the U.S., Canada and Mexico only and gives you specific legal rights. You may also have other rights which vary from state to state or country to country.