



For Replacement Parts, Call 1-800-543-6400

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address parts correspondence to:

- The Campbell Group / Attn: Parts Dept.
- 100 Production Drive
- Harrison, OH 45030

Ref. No.	Description	Part Number	Qty.	Ref. No.	Description	Part Number	Qty.
1	Tank - 30 gallon vertical	AR040201AJ	1	32	Pulley - 3" outside diameter	PU012600AG	1
	Tank - 60 gallon vertical	AR040000JJ	1		Pulley - 3.25" outside diameter	PU012700AG	1
2	Drain cock - 60 gallon vertical	D-1401	1	33	Square hd set screw	ST012200AV	1
3	Electric motor (1 phase models)	MC006101AJ	1	34	Belt guard (back) - molded type	BG217902AV	1
	Electric motor (3 phase models)	MC083400AV	1	35	Plascrew	ST058502AV	1
4	Key	KE000903AV	1	36	Belt guard (front) - molded type	BG217800AV	1
5	Hex head screw	ST016000AV	4	37	Self-tapping screw	ST073269AV	1
6	Washer	ST011200AV	4	38	Self-tapping screw	ST042400AV	3
7	Locknut	ST146000AV	4	39	Pleated paper filter element	ST073916AV	1
8	Nipple	HF002401AV	1	40	Metal canister filter assembly	ST073915AV	1
9	Pressure switch (models VT5595, VT5587, VT6395)	CW209300AV	1	41	Belt guard (back) - wire type	BG217601AV	1
	Pressure switch (models VT6276, VT6242)	CW210700AJ	1	42	Belt guard (front) - wire type	BG217701AV	1
10	Strain relief (motor cord) (1 phase models)	CW209700AV	1	43	#10 Flatwasher	ST070906AV	6
11	Motor cord (1 phase models)	EC012800AV	1	44	#10-24 Nut	ST163200AV	4
12	ASME Safety valve	V-215105AV	1	45	#10-24 - 5/16" Self-tapping screw	ST042400AV	2
13	Plug	ST022500AV	1	46	Δ General warning decal set	DK630000AV	1
14	Tank pressure gauge - 2" face type	GA016700AV	1	47	Δ Moving and mounting warning decal	DK364601AV	1
	Tank pressure gauge - 1.5" face type	GA016300AV	1	48	Δ Reducer bushing - 3/4 NPT	PG201002AV	1
	Reducer bushing for 1.5" gauge	ST071407AV	1		Δ Reducer bushing - 1/4 NPT	PG201004AV	1
15	Unloader valve	CW221000AV	1		Δ Reducer bushing - 3/8 NPT	PG201006AV	1
16	Check valve	CV221502AJ	1		Δ Reducer bushing o-ring	ST070190AV	2
17	Check valve ferrule (rubber)	ST067300AV	1	49	Dipstick/breather	VT041701AJ	1
18	Discharge tube	VT043300AP	1	50	Strain relief screw	ST209800AV	1
19	Compression nut	ST033101AV	1	KITS			
20	Push-in fitting	ST081301AV	1		Δ Tank drain extension kit	MP3456	1
21	Unloader tube	ST117802AV	1		Δ Isolation pad kit (includes rubber and metal mounting pads, mounting screws and concrete anchors)	MP3445	1
22	Pump	VT470000KB	1		Δ Maintenance kit (includes filter elements, oil and maintenance log card)	MP3449	1
	Pump - with sight glass	VT4721	1		Δ Start-up kit (includes 2 qts compressor oil, tank shut-off valve and isolation pad kit (MP3445))	MP3444	1
23	Oil drain plug	ST022300AV	1		Δ Not shown		
24	Oil drain cap	ST150100AV	1				
25	Oil drain extension - some models	ST083800AV	1				
26	Compression assembly	ST018300AV	1				
27	Self-tapping screw	ST016500AV	4				
28	Belt	BT020400AV	1				
29	Flywheel	PU015900AG	1				
30	Key	KE000900AV	1				
31	Setscrew	ST026200AV	1				